How to adjust the display brightness on a Classic Stereo?

Customer Support - 2025-09-29 - Classic Stereo

Would you like to adjust the brightness of the display on your Classic Stereo?

1. To customise the display brightness, press the "**Home**" button to access the main menu.
2. Use the "**Volume/Select**" dial to scroll to "**System settings**" and press the dial to select.
3. Scroll through the settings options until you find "**Backlight**" and press the dial to enter.

You'll see three options: "**Timeout**", "**On Level**" and "**Dim Level**".

1. Select the "**Timeout**" to define the duration until the display brightness changes from "**On Level**" to "**Dim Level**".
2. Select "**On Level**" to adjust the brightness when the radio is on, and "**Dim Level**" to adjust the brightness of the display when the radio enters dim mode. It is even possible to turn the display completely off in Dim mode. You can set the display to be brighter when you're actively using it and dark in Dim mode.

And there you go! You can now easily adjust the display brightness of your Classic Stereo radio to match your environment and preferences.