



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic H4](#) > [How to change the source on a Classic H4?](#)

How to change the source on a Classic H4?

Customer Support - 2025-07-24 - [Classic H4](#)

You would like to change the source that is playing on your Classic H4?

The available sources are **DAB, FM, Bluetooth, Aux In** and **USB**.

1. To choose a source for playback, simply tap on the "**Source**" button of your Classic H4 to open the selection window.
2. Pressing the "**Source**" button repeatedly, or turning the "**Select**" dial will cycle through the available sources.
3. To confirm your selection, press the "**Select**" dial.