How to select the different Lighting modes

Customer Support - 2025-08-07 - Classic Aura

You wish to select from the different Lighting modes of your Classic Aura?

Set the mood with immersive lighting modes, from a steady glow to dynamic effects like an aurora, fire, or beat-synced disco.

Use the controls on top of the speaker to quickly switch between modes and match the ambiance to your music.

Ambient light – Tap the button to turn it on or off. Press and hold the button for 2 seconds to select the brightness.

Colour gradients – Tap the button to switch between the different moods. You can choose between Sunset, Blossom, Lilac, Leaf and Coral.

Dynamic effects – Tap the button to switch between the different effects. Here you can choose between Disco Beat (synchronised to music), Energetic Fire, Aurora Borealis, Colour Pulse and Calm Ocean.