



FAQs > Woodland Series - Outdoor Speakers/Radios > How to use the Power Bank function of the Woodland Glow?

How to use the Power Bank function of the Woodland Glow?

Customer Support - 2025-01-27 - Woodland Glow

You want to charge a mobile device with your Woodland Glow?

To charge a mobile device with your Woodland Glow, simply use the **Power Bank** function.

The **USB-A connector** on the back of your Woodland Glow can be connected to your mobile phone or other device to be charged.

Charging an external device **will reduce the battery runtime** of your Woodland Glow.