



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Aura](#) > [¿Cómo cargar mi altavoz Classic Aura y comprobar el estado de la batería?](#)

¿Cómo cargar mi altavoz Classic Aura y comprobar el estado de la batería?

Customer Support - 2025-08-08 - [Classic Aura](#)

¿Deseas cargar tu Classic Aura y comprobar el estado de la batería?

1. Classic Aura requiere un cargador USB-C de entre 5 W y 30 W.

Se requieren 30 W para una velocidad de carga óptima y para permitir el volumen máximo durante la carga.

1. Conecta el altavoz al cargador USB-C.






El icono Eco (batería) parpadeará durante la carga.

1. Una vez cargado al 100 %, el icono Eco (batería) dejará de parpadear.






También puedes comprobar el estado de la carga mientras escuchas pulsando el botón Eco durante 2 segundos.

Los 4 LED situados encima del dial de volumen se iluminarán para indicar el estado actual de la batería.



Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
75%	100%	high	high	high	blink	
45%	75%	high	high	blink	off	
25%	45%	high	blink	off	off	
5%	25%	high	off	off	off	
0%	5%	blink	off	off	off	

High
 Low
 Pulse
 Blink
 Off

Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
95%	100%	on	on	on	on	
75%	95%	on	on	on	pulse	
45%	75%	on	on	pulse	off	
25%	45%	on	pulse	off	off	
0%	25%	pulse	off	off	off	

High
 Low
 Pulse
 Blink
 Off