



[FAQs](#) > [Evoke Series - Modern Music Systems](#) > [Evoke Home II](#) > [How do I search for and select DAB stations?](#)

How do I search for and select DAB stations?

Customer Support - 2026-09-04 - [Evoke Home II](#)

Would you like to search for and select DAB+ radio stations on your Evoke Home II?

If you have skipped the network setup and have selected DAB for the first time, your Evoke Home II will automatically start a DAB scan.

All available stations will be found and saved to the DAB station list.

To change the DAB station,

1. press the 'List' button to display the current station.
2. Press the button again to open the 'Station List'.
3. Turn the dial to scroll through the list of available stations.
4. Once you have found the station of your choice, press the dial to switch to that station.
5. Your first 3 presets can also be accessed by pressing the direct-access preset buttons.
6. The 4th button opens the preset list.

To perform a new scan,

1. simply press the Home button whilst in DAB mode, select the 'DAB Configuration' option, and confirm by pressing the control dial.
2. Now select the DAB scan and confirm again.
3. Your radio will then delete all saved DAB stations and automatically start scanning for all available stations.