



지식 베이스 > Smart Speakers > DiscovR > General Questions > How do I check my speaker's battery level?

How do I check my speaker's battery level?

Laura - 2021-10-19 - General Questions

To check the current battery level, press and hold the source button. The number of illuminated segments on the light ring will indicate the current level of charge remaining.