



FAQs > Classic Series - DAB+ and Music Systems > Classic Stereo > How to save/recall presets on a Classic Stereo?

How to save/recall presets on a Classic Stereo?

Customer Support - 2024-11-28 - Classic Stereo

You would like to save a preset or recall a preset on your Classic Stereo?

The Classic Stereo allows you to save up to **20** presets for **Internet Radio / Podcasts** (shared), for **DAB+** and **FM**.

1. To store a station to the preset list, long press the "**Preset list**" button until the "**Save to Preset**" list opens.
 2. Turn the "**Volume/Select**" dial to choose the position within the list (1-20) and press the "**Volume/Select**" dial to confirm. The station listened to is now saved on the chosen preset.
 3. This can also be done using your remote control. It also offers **4 Quick Access buttons**, allowing you to save and recall **presets 1-4**.
-
1. To recall a preset, short press the "**Preset list**" button (also available on your remote control), select the station you would like to listen to, and confirm by pressing the "**Volume/Select**" dial (or "**Select**" button on the remote).