



FAQs > Evoke Series - Modern Music Systems > Evoke Play > How can I save/recall presets on my Evoke Spot/Play?

---

## How can I save/recall presets on my Evoke Spot/Play?

Customer Support - 2024-11-14 - Evoke Play

# You would like to save a preset or recall a preset on your Evoke Spot/Play?

The Evoke Spot/Play allows you to save up to **40** presets for **Internet Radio** or **Podcasts** (shared), and **10** each for **DAB** and **FM** stations.

1. To store a station/podcast to the preset list, long press the preset list button until the **"Save to Preset"** list opens.
  2. Use the up/down arrow keys to choose the position within the list and press the **"Home/select"** button to confirm. The station/podcast listened to is now saved on the chosen preset.
- 
1. To recall a preset, short press the **"Favourite"** button, select the station/podcast you would like to listen to, and confirm by pressing the **"Home/select"** button.
  2. Your first 4 presets can also be recalled by pressing the direct access preset buttons beneath the Volume encoder.