



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Aura](#) > [Hoe laad ik mijn Classic Aura-luidspreker op en controleer ik de batterijstatus?](#)

Hoe laad ik mijn Classic Aura-luidspreker op en controleer ik de batterijstatus?

Customer Support - 2025-08-08 - [Classic Aura](#)

Wil je je Classic Aura opladen en de batterijstatus controleren?

1. Voor de Classic Aura heb je een USB-C-oplader van 5 W tot 30 W nodig.

30 W is nodig voor de snelste oplaadtijd en om tijdens het opladen het maximale volume te kunnen gebruiken.

1. Sluit de speaker aan op de USB-C-oplader.

Het Eco-pictogram (batterij) knippert tijdens het opladen.





1. Zodra het apparaat 100% is opgeladen, stopt het Eco-pictogram (batterij) met knipperen.

Je kunt de oplaadstatus ook controleren tijdens het luisteren door de Eco-knop 2 seconden ingedrukt te houden.

De 4 LED's boven de volumeknop geven de huidige batterijstatus aan.



Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
75%	100%	high	high	high	blink	
45%	75%	high	high	blink	off	
25%	45%	high	blink	off	off	
5%	25%	high	off	off	off	
0%	5%	blink	off	off	off	

Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
95%	100%	on	on	on	on	
75%	95%	on	on	on	pulse	
45%	75%	on	on	pulse	off	
25%	45%	on	pulse	off	off	
0%	25%	pulse	off	off	off	