



FAQs > Classic Series - DAB+ and Music Systems > Classic C-D6 > How to scan and select DAB stations on a Classic C-D6?

---

## How to scan and select DAB stations on a Classic C-D6?

Customer Support - 2024-10-22 - Classic C-D6

### **You would like to search for DAB+ radio stations and select them on your Classic C-D6?**

When you use Classic C-D6 for the first time, the DAB scan happens automatically. All available stations are found and saved in the "**Station List**".

To change the DAB station,

1. Turn the "**Select**" dial by one click while being in DAB mode. The "**Station List**" will appear.
2. You can now scroll through the available stations by turning the dial.
3. Once you've found the station of your choice, press the "**Select**" dial to switch to that station.

For a **new scan** simply press the "**Home**" button while being in DAB mode and select the option "**DAB Scan**".

Your radio will then delete all stored DAB stations and automatically begin scanning for all available stations.