



[Baza Wiedzy](#) > [Help by Connection Type \(BT, Internet,...\)](#) > [Internet Radios](#) > [Evoke Spot / Play / Home](#) > [Evoke Home - Displaying the file name in CD mode](#)

## Evoke Home - Displaying the file name in CD mode

Customer Support - 2025-02-04 - [Evoke Spot / Play / Home](#)

### **Additional information to the owner's manual**

As stated in the owner's manual, your Evoke Home will also display the file name if this is available.

This is limited to ID3 metadata of MP3 and WMA tracks recorded on a CD and does not include CD-Text information used on some commercial pre-recorded audio CDs.

By long pressing the info key during CD playback, you can toggle through the following information:

1. Filename
  2. Album
  3. Artist
  4. Song name
  5. Date
- Etykiety
  - [CD Text](#)
  - [Evoke Home](#)
  - [File Name](#)
  - [Titel](#)
  - [Title](#)