



[Baza Wiedzy](#) > [Elan Series - DAB+ Radios](#) > [Elan Move](#) > [How to save/recall presets on an Elan Move?](#)

## How to save/recall presets on an Elan Move?

Customer Support - 2026-03-27 - [Elan Move](#)

### You would like to save a preset or recall a preset on your Elan Move?

The Elan Move allows you to save up to **40** presets for **DAB+** and **FM** radio.

1. To store a station to the **first 2 presets**, long press one of the „**Favourite 1/2**“ button until "**Preset xx stored**" is displayed.
2. Press the "**Favourite List**" button to choose the a position within the list (1-40) and press the "**Select**" (>|) button to confirm. The station listened to is now saved on the chosen preset.
3. To recall a preset, short press the "**Favourites**" button, select the station you would like to listen to by using the "**Stations**" "**Skip Forward**" (>|) or "**Skip Back**" (<|)" buttons and confirm by pressing the "**Select**" (>|) button.