



Baza Wiedzy > Woodland Series - Outdoor Speakers/Radios > How to switch a Woodland on and off?

How to switch a Woodland on and off?

Customer Support - 2024-10-29 - Woodland

You would like to know how to switch your Woodland on and off?

Pressing the "**Standby**" on/off button will boot your Woodland.

When you use Woodland for the first time, the unit will automatically enter a DAB scan.

All available stations are found and saved to the station list without you having to do anything.

To switch the Woodland off, keep the "**Standby**" button pressed until "**Goodbye**" is displayed, and the unit switches off.