



[Baza Wiedzy](#) > [More products](#) > [Jongo](#) > [My Jongos LED is changing between amber, green and red](#)

My Jongos LED is changing between amber, green and red

Sarah Spencer - 2021-10-19 - [Jongo](#)

My Jongos LED is changing between amber, green and red

This is your Jongo updating its software. Do not power off your Jongo while this is happening. This process may take up to 5 minutes to complete. When the LED is a constant green the update is complete and you can continue using your Jongo.