How do I set up ASA on my Bloom radio? (Automatic Safety Alerts)

Customer Service - 2026-11-26 - Bloom

How do I set up ASA on my Bloom radio? (Automatic Safety Alerts)

The Bloom radio is ASA-certified and supports the Automatic Safety Alert (ASA) system.
For more information about ASA and how it works, see our ASA FAQ article.

Before you start, make sure that your Bloom radio is switched on.

1. Press the **Home** button and select **Settings** using the dial. Press the dial to confirm.
2. Select **ASA Warning System**, then select **Setup**.
3. If you already have your ASA location code, continue to step 5.
4. If you do not have a location code, get one from asa.radio:
    - Press the dial to display the QR code and scan it with your mobile device.
    - Or open asa.radio directly in a web browser.
    - Enter your location on the website to receive your ASA location code.
5. In the **ASA Setup** menu, select **Enter Code**.
6. Use the dial to enter the location code. Press the dial to confirm each digit.
7. The ASA setup is complete. You can also adjust the alert volume in the **ASA Setup** menu.