



[FAQs](#) > [Elan Series - DAB+ Radios](#) > [Elan One<sup>2</sup> - Quick Help](#)

## Elan One<sup>2</sup> - Quick Help

Customer Support - 2025-07-18 - [Elan Series - DAB+ Radios](#)

### Our most important tips for using your portable Elan One<sup>2</sup>

1. **Before operating the product**, you should always read the [Elan One<sup>2</sup> Quick Start Guide.](#)

You can find the QSG for the Elan One<sup>2</sup> in our [Download Centre](#).

1. **Before we start**, let's point out the obvious.

Make sure the antenna is fully extended and all plastic covers have been removed. Connect your device to a power source via a USB power adapter (not included) or insert 4 AA batteries according to the +/- markings.

Make sure that the slider on the side is in the ON position.

1. **Switching Elan One<sup>2</sup> on/off**

Press the "Volume/Select" dial to switch on your Elan One<sup>2</sup>.

Want to [find out more?](#)

1. [Scanning and selecting DAB+ or FM stations](#)

We have two separate articles on these topics, which you can select by clicking on the highlighted words.

1. **Saving or recalling a preset**

The Elan One<sup>2</sup> allows you to save your favourite stations to the quick access buttons.

More details can be found [here](#).

1. **Changing the source**

This is kept straight forward. Pressing the "Source" button will select the source played. If you want to know more about the source options, read this article [\*\*here\*\*](#).

### **1. Setting an alarm**

The Elan One<sup>2</sup> has 2 different alarm clocks that you can set. We have created a detailed [\*\*step-by-step help article\*\*](#) to explain the details.

### **1. Pairing a Bluetooth device**

When you select Bluetooth as the source, pairing mode is activated. More detailed instructions on how to find your Elan One<sup>2</sup> on the device to be paired and further information on pairing with BT can be found [\*\*here\*\*](#).

### **1. Adjusting the display brightness**

The brightness of the display of your Elan One<sup>2</sup> can be adjusted. [\*\*Find out how.\*\*](#)