

FAQs > Classic Series - DAB+ and Music Systems > Classic H4 > Classic H4 - Quick Help

Classic H4 - Quick Help
INSIDE / AOIPA - 2025-01-22 - Classic H4

Our most important tips on how to use your Classic H4

- Before operating the product, always consult the <u>Classic H4 Quick Start Guide</u>.
 You can find the QSG for Classic H4 in our Download Center here: <u>Classic H4 Quick</u>
 Start Guide
- 1. Before we start, we state the obvious. Please make sure your device is connected to a power source, the antenna is fully extended and all plastic covers are removed

1. Switching Classic H4 on/off

Pressing the Standy on/off button will boot your Classic H4 to the last source listened. When you use Classic H4 for the first time, the unit will automatically enter a DAB scan. All available stations are found and saved to the "Station List" without you having to do anything.

1. Scanning and selecting DAB+ or FM Stations

We have two separate articles on these topics that you can select by clicking on the highlighted words.

1. Saving or recalling a preset

"The Classic H4 offers two methods to save presets. These can either be saved to one of the 4 quick preset buttons or added to the preset list.

Pressing one of the quick preset buttons until "Preset stored"" appears, will save the station currently listened to. Short press the preset button to recall it. More details can be found **here.**

1. Changing the source

This is kept straight forward. Pressing the "Source" button will open the source window. If

you want to know more about the source options, read this article here.

1. Pairing a Bluetooth device

Press the BT button and the Classic H4 will enter pairing mode. More detailed instructions on how to find your Classic H4 on the device you want to pair and more on pairing with BT can be found **here.**

1. Setting an alarm

The Classic H4 has 2 different alarms you can set. We have created a help detailed step-by-step help article to explain the details **here.**

1. Adjusting the display brightness in Standby and on mode

Classic H4 gives you various customization options to adjust your display brightness. Each of these functions is described in the respective help article linked **here**.